

THE 7 STEPS TO A DURABLE WOOD REPAIR



1. Remove paint & dirt



2. Remove all decay



3. Prime with DRY FIX®



4. Apply DRY FLEX®



5. Shape and finish repair



6. Sand finished repair



7. Apply paint finish



THE 7 STEPS TO A DURABLE WATERTIGHT SEAL



1. Check adhesion



2. Remove loose putty

Cut the nozzle
to form the
glazing profile



3. Clean and sand rebate



4. Prime rebate



5. Apply DRY SEAL™



6. Smooth the surface
by holding the
applicator up-right



7. Apply paint finish

Please visit
our website to view
our application
technique video.

