

DRY FLEX® SUPER FINISH 2-in-1 150ml

For durable and fast filling



DRY FLEX®



Instructions for the use of our new 150ml 2-in-1 cartridge

- The new 150ml 2-in-1 cartridge can be used in combination with the EASY-Q™ single dispensing gun.
- The A component is now 'wrapped' around the B component when dosing the product. Please see the image below for reference.
- Due to the mixing ratio, the B component (white) will dispense first, followed by the A component (brown). This is normal and there is no need to remove the excess.
- Mixed and cured product may be disposed of with residual waste.
- The empty cartridge (except for the nozzle, which still contains unmixed product) can also be disposed with residual waste. The nozzle should be disposed of with chemical waste.

Front view of nozzle

